



SAMSUNG

**MICROWAVE OVEN
M1933CE**

**Owner's Instructions
and
Cooking Guide**








Code No. : DE68-00364A

Contents






- Quick Look-up Guide 2
- Oven 4
- Control Panel 5
- Accessories 6
- Using this Instruction Booklet 7
- Safety Precautions 8
- Installing Your Microwave Oven 10
- Setting the Time 10
- How a Microwave Oven Works 11
- Checking that Your Oven is Operating Correctly 12
- What to Do if You are in Doubt or Have a Problem 12
- Cooking/Reheating 13
- Power Levels 13
- Stopping the Cooking 14
- Adjusting the Cooking Time 14
- Setting a Standing Time 15
- Using the Instant Reheat/Cook Feature 16
- Instant Reheat/Cook Settings 17
- Using the Auto Defrost Feature 18
- Auto Defrost Settings 19
- Multistage Cooking 20
- Switching the Beeper Off 21
- Safety-locking Your Microwave Oven 21
- Remembering Function 22
- Cookware Guide 23
- Cooking Guide 24
- Cleaning Your Microwave Oven 32
- Storing and Repairing Your Microwave Oven 33
- Technical Specifications 34

Quick Look-up Guide

If you want to cook some food

- 1  Place the food in the oven.
Select the power level by pressing the  button once or more times.
- 2  Select the cooking time by pressing the **10min**, **1min** or **10s** buttons as required.
- 3  Press the  button.
Result: Cooking starts.
The oven beeps four times when cooking is over.

If you want to defrost some food

- 1  Place the frozen food in the oven.
Press the **Auto** () button once or more time according to the type of food to be defrosted. Refer to the table on the page 18 for further details..
- 2  Select the weight by pressing the **kg** and **g** buttons as required.
- 3  Press the  button.

If you want to add an extra minute

- 1  Leave the food in the oven.
Press **+30s** once or more times for each extra 30 seconds that you wish to add.

Checking that Your Oven is Operating Correctly

The following simple procedure enables you to check that your oven is working correctly at all times.

First, place a bowl of water on the turntable.



1 Press the  button and set the time to 4-5 minutes by pressing the 1min button the appropriate number of times.





2 Press  button.
Result: The oven heats the water for 4 to 5 minutes. The water should then be boiling.

The oven must be plugged into an appropriate wall socket. The turntable must be in position in the oven. If a power level other than the maximum is used, the water takes longer to boil.

What to Do if You are in Doubt or Have a Problem


If you have any of the problems listed below try the solutions given.



- This is normal.
 - Condensation inside the oven
 - Air flow around the door and outer casing
 - Light reflection around the door and outer casing
 - Steam escaping from around the door or vents
 - The oven does not start when you press the  button.
 - Is the door completely closed?
 - The food is not cooked at all
 - Have you set the timer correctly and/or pressed the  button?
 - Is the door closed?
 - Have you overloaded the electric circuit and caused a fuse to blow or a breaker to be triggered?
 - The food is either overcooked or undercooked
 - Was the appropriate cooking length set for the type of food?
 - Was an appropriate power level chosen?
 - Sparking and cracking occur inside the oven (arcing)
 - Have you used a dish with metal trimmings?
 - Have you left a fork or other metal utensil inside the oven?
 - Is aluminium foil too close to the inside walls?
 - The oven causes interference with radios or televisions
 - Slight interference may be observed on televisions or radios when the oven is operating. This is normal. To solve this problem, install the oven away from televisions, radios and aerials.
 - If interference is detected by the oven's microprocessor, the display may be reset. To solve this problem, disconnect the power plug and reconnect it. Reset the time.
- If the above guidelines do not enable you to solve the problem, contact your local dealer or SAMSUNG after-sales service.


Cooking / Reheating

The following procedure explains how to cook or reheat food. ALWAYS check your cooking settings before leaving the oven unattended.


First, place the food in the centre of the turntable and close the door




1 Press the  button.
Result: The 1000W (maximum cooking power) indications are displayed. Select the appropriate power level by pressing the  button again until the corresponding wattage is displayed. Refer to the power level table on the next page.



2 Set the cooking time by pressing the 10min, 1min and 10s button.




3 Press the  button.
Result: The oven light comes on and the turntable starts rotating. Cooking starts and when it has finished the oven beeps four times.



Never switch the microwave oven on when it is empty.

➤ If you wish to heat a dish for a short period of time at maximum power(1000W), simply press the +30s button once for each 30 seconds of cooking time. The oven starts immediately.

Power Levels


You can choose among the power levels below.



Power Level	Output
FULL	1000 W
HIGH	850 W
MEDIUM HIGH	600 W
MEDIUM	450 W
MEDIUM LOW	300 W
DEFROST ()	180 W
LOW	100 W



-  if you select higher power level, the cooking time must be decreased.
-  if you select lower power level, the cooking time must be increased.



Stopping the Cooking

You can stop cooking at any time to check the food.

- 


1 To stop temporarily:
Open the door.
Result: Cooking stops. To resume cooking, close the door and press  again.
- 


2 To stop Completely:
Press the  button.
Result: The cooking stops.
If you wish to cancel the cooking settings, press the **Cancel**() button again.

 You can also cancel any setting before starting by simply pressing **Cancel** ().

Adjusting the Cooking Time

You can increase the cooking time by pressing the **+30s** button once for each 30 seconds to be added.

- 
- Press the **+30s** button once for each 30 seconds to be added.


 You can not adjust the time during cooking when Auto modes are selected.



Setting a Standing Time


The Hold Timer can be used in two different ways:


- ◆ As a simple cooking timer
- ◆ To set a standing time for defrosting.


 As a simple cooking timer.

- 

1 Press the  button.
- 

2 Select the required time by pressing the **10min**, **1min**, and **10s** buttons.
- 

3 Press the  button.
Result: The oven beeps four times when the standing time is over.

 To set the standing time during defrosting. See page 20.

Using the Instant Reheat/Cook Feature

With the Instant Reheat and Cook feature, the cooking time is set automatically and you do not have to press the  button. You can adjust the number of servings by pressing the appropriate Instant Reheat and Cook button the required number of times.


First, place the food in the centre of the turntable and close the door.



Press the Instant Reheat and Cook button which you want the required number of times.

Result: Cooking starts after about two seconds. When it has finished:







- 1) The oven beeps four times.
- 2) The end reminder signal will beep 3 times (once every minute).
- 3) The current time is displayed again.

Example: Press the  button three times to reheat three cups of coffee. Refer to the table below.

Use only recipients that are microwave-safe.

Instant Reheat / Cook Settings(continued)

The following table presents the various Instant Reheat & Cook Programmes, quantities, standing times and appropriate recommendations.

Button	Food	Serving Size	Standing Time	Recommendations
	Ready Meal	300-350 g Chilled 500-550 g	3 mins 400-450 g	Put the meal on a ceramic plate and cover it with microwave cling film. This programme is suitable for the meals consisting of 3 components e.g. meat with sauce, vegetables and side dishes like potatoes, rice or pasta.
	Drinks Coffee, milk, tea, water	150 ml (1 cup) 300 ml (2 cups) 450 ml (3 cups) 600 ml (4 cups)	1-2 mins	Pour the liquid into ceramic cups and reheat uncovered. Place 1 cup in the centre, 2 cups opposite of each other and 3 or 4 cups in a circle. Leave them to stand in the microwave oven. Stir the drinks before and after standing time and be careful while taking the cups out (see safety instructions for liquids).
	Soup/Sauce Chilled	200 - 250 ml 300 - 350 ml 400 - 450 ml 500 - 550 ml 600 - 650 ml	2-3 mins	Pour the soup/sauce into a deep ceramic soup plate or bowl and cover during heating and standing time. Stir before and after standing time.
	Fresh vegetables	200 - 250 g 300 - 350 g 400 - 450 g 500 - 550 g 600 - 650 g 700 - 750 g	3 mins	Weigh the vegetables after washing, cleaning and cutting into a similar size. Put them into a glass bowl with lid. Add 45 ml (3 tablespoons) water when cooking 200-450 g, add 60 ml (4 tablespoons) for 500-650 g and add 75 ml (5 tablespoons) for 700-750 g. Stir after cooking. (When cooking bigger quantities, stir once during cooking.)
	Boiled Potatoes / Peeled Potatoes	200 - 250 g 300 - 350 g 400 - 450 g 500 - 550 g 600 - 650 g 700 - 750 g	3 mins	Weigh the potatoes after peeling, washing and cutting into a similar size. Put them into a glass bowl with lid. Add 45 ml (3 tablespoons) water when cooking 300-450 g, add 60 ml (4 tablespoons) for 500-650 g and add 75 ml (5 tablespoons) for 700-750 g.
	Fresh Fish	200 - 250 g 300 - 350 g 400 - 450 g 500 - 550 g 600 - 650 g 700 - 750 g	3 mins	Rinse with water and sprinkle with lemon juice. Use a microwave suitable glass or ceramic dish. Lay whole fishes head to tail. Cover with microwave cling film during heating and standing time.