

ASSEMBLY:

1. Check the filters are in place correctly.

Insert the flexible hose in the air intake at the front side of the appliance. Press until it clicks into position.

2. Extension tubes with hose:
Fit the extension tube to the flexible hose.

Fit the floor brush to the extension tube.






3. Power cable:

Before using the appliance, unwind a sufficient length of cable and insert the plug into the power socket. A yellow mark on the power cable shows the ideal cable length. **Do not** expend the cable beyond the red mark.

To rewind the power cable, press the rewind button. Guide the cable with one hand to ensure that it does not whip causing damage.

4. Switch on:

Press the on/off button to switch the appliance on.



5. With the speed adjust button you can change the suction power. By turning the wind control knob on handle, the suction power can be adjusted.


Air Adjustment

6. Storing the vacuum cleaner:
Plug the orientation pin of the tube into the orientation hole.

Accessories:

Floor brush: Ideal for the daily cleaning on carpets and hard floors.

1. For hard floors: Press the selector switch, till the brush appears.
2. For carpet: **Do not** press the selector switch.



3. Accessory list:

Floor brush	Hard floor or carpet
Crevice tool	For radiators, crevices, corners, baseboards and between cushions.
Upholstery brush	For sofa, furniture etc.

Cleaning and care:

1. Clean the HEPA-Filter and motor filter: The dust filter needs regular checks and should be changed at once, when it is full (Max-mark in container). Open the front cover and take out the HEPA-Filter. Tap the HEPA-Filter over a dustbin. (Cloth HEPA-Filter can be washed with water).

Motor filter: Open the front cover and take out the dust filter bag. Take out the motor filter. Wash the filters with tap water and dry in the shade. Fix the filter again.

2. Air filter: The air filter needs regular service.

Open the rear cover and take out the filter piece from the protective lattice. Wash the filters with tap water and dry in the shade. Fix the filter again.

CAUTION: Unplug the appliance form the mains supply socket after use and before every cleaning.