



MICROWAVE OVEN

OWNER'S MANUAL

PLEASE READ THIS OWNER'S MANUAL THOROUGHLY BEFORE OPERATING.

MS-1947C

Micro Power Cooking

In the following example I will show you how to cook some food on 80% power for 5 minutes and 30 seconds.



Your oven has five microwave Power settings. High power is automatically selected but repeated presses of the **POWER** button will select different power levels.

POWER	Press POWER	%	POWER OUTPUT
HIGH MAX	1 time	100%	800W
MEDIUM HIGH	2 times	80%	640W
MEDIUM	3 times	60%	480W
DEFROST MEDIUM LOW	4 times	40%	320W
LOW	5 times	20%	160W

Make sure that you have correctly installed your oven as described earlier in this book.

Press **STOP/CLEAR**.

 **STOP
CLEAR**

 **START
Q-START**

Press **POWER** twice to select 80% power.
"640" appears on the display.

POWER
CLOCK

**QUICK
DEFROST**

Time/Weight
+
—

Press **1 MIN** five times.
Press **10 SEC** three times.

10 min.

1 min.

10 sec.

Press **START/QUICK START**.

After cooking is over, End Reminder Beep Sounds per 1 minute for 5 minutes until the oven door is opened.

 **STOP
CLEAR**

 **START
Q-START**

Micro Power

Level

Your microwave oven is equipped with 5 power levels to give you maximum flexibility and control over cooking. The table below shows the examples of food and their recommended cooking power levels for use with this microwave oven.

POWER LEVEL	USE	POWER LEVEL (%)	POWER OUTPUT
HIGH	<ul style="list-style-type: none">* Boil Water* Brown minced beef* Cook poultry pieces, fish, vegetables* Cook tender cuts of meat	100%	800W
MEDIUM HIGH	<ul style="list-style-type: none">* All reheating* Roast meat and poultry* Cook mushrooms and shellfish* Cook foods containing cheese and eggs	80%	640W
MEDIUM	<ul style="list-style-type: none">* Bake cakes and scones* Prepare eggs* Cook custard* Prepare rice, soup	60%	480W
DEFROST/ MEDIUM LOW	<ul style="list-style-type: none">* All thawing* Melt butter and chocolate* Cook less tender cuts of meat	40%	320W
LOW	<ul style="list-style-type: none">* Soften butter & cheese* Soften ice cream* Raise yeast dough	20%	160W



Two stage Cooking

In the following example I will show you how to cook some food in two stages. The first stages will cook your food for 11 minutes on HIGH; the second will cook for 35 minutes on 320W.



During two stage cooking the oven door can be opened and food checked. Close the oven door and press **START** and the cooking stage will continue.

At the end of stage1, BEEP sounds and stage 2 commences.

Should you wish to clear the programme press **STOP/CLEAR** twice.

Press **STOP/CLEAR**.



**STOP
CLEAR**

**START
Q-START**

Set the power and the cooking time for **stage1**.

Press **POWER** once to select HIGH power.

Press **10 MIN** once.

Press **1 MIN** once.

Set the power and the cooking time for **stage2**.

Press **POWER** four times to select 320 power.

Press **10 MIN** three times.



Press **1 MIN** five times.

Press **START/QUICK START**.



**STOP
CLEAR**

**START
Q-START**



Quick Start

In the following example I will show you how to set 2 minutes of cooking on high power.



The **QUICK START** feature allows you to set 30 seconds intervals of HIGH power cooking with a touch of the **START** key.

Press **STOP/CLEAR**.




**STOP
CLEAR**



**START
Q-START**

Press **START** four times to select 2 minutes on HIGH power.

Your oven will start before you have finished the fourth press.




**STOP
CLEAR**



**START
Q-START**

During **QUICK START** cooking, you can extend the cooking time up to 10 minutes by repeatedly pressing the **START** key.



In the following example I will show you how to cook 0.5 kg of jacket potato.



AUTO COOK allows you to cook most of your favorite food easily by selecting the food type and entering the weight of the food by pressing the MORE/LESS key.

CATEGORY	Press AUTO COOK
JACKET POTATO	1 time
FRESH VEGETABLE	2 times
FROZEN VEGETABLE	3 times
RICE/PASTA	4 times
FISH	5 times

Press **STOP/CLEAR**.

Press **AUTO COOK** one time.
"AC-1" appears on the display.

Select desired weight of potato.
Press **MORE** key five times to enter 0.5kg.

Press **START/QUICK START**.

 **STOP
CLEAR**

 **START
Q-START**

AUTO COOK



- 1. Jacket Potato 2. Fresh Vegetable
- 3. Frozen Vegetable 4. Rice / Pasta
- 5. Fish

POWER
CLOCK

**QUICK
DEFROST**

Time/Weight

+

-

 **STOP
CLEAR**

 **START
Q-START**